



## RHS S76 PROLONGATOR – R&O MAINTENANCE MANUAL SUPPLEMENT

### MODELS: SIKORSKY S76B & C

Read all of the Instructions for Continuing Airworthiness thoroughly prior to performing any activities relating to this product

	Transport Canada
Design Approval Representative No. 326	
APPROVED	
By	
Appr'l No.	C-RH14-106/D
Appr'l Date	2014-06-03
Issue No.	1
Issue Date	2014-06-03
YY-MM-DD	



## **Table of Contents**

<u>Section</u>	<u>Description</u>	<u>Page</u>
1	Description	2
2	Aircraft Applicability	3
3	Weight & Balance	3
4	Maintenance/Inspection Section	3
5	Repair Procedures	3

## **General Notes**

1. All R&O Instructions shall be accomplished in accordance with (IAW) standard aircraft practices. Refer to the current revision of the FAA manuals AC 43.13-1B and AC 43.13-2B for details on standard aircraft practices.
2. All Fasteners shall be torqued to standard aircraft specifications, unless otherwise specified. Refer to the current revision of the FAA manuals AC 43.13-1B and AC 43.13-2B for details on standard torque specifications.
3. All Dimensions are in imperial measures (inches/pounds).
4. If changes to this document are required, Alpine Aerotech LP shall revise all pages and reissue the entire document.
5. Alpine Aerotech LP shall make any subsequent revisions of this document available free of charge upon request. Alpine Aerotech LP also recommends that the end user of this product periodically verify the revision level of this document.

## **Section 1: Description**

The purpose of the RHS S-76 Exhaust Prolongator, R&O, Kit is to provide an economical method of repairing the Exhaust Prolongator, Assy when the assy begins to wear out.



**Section 2: Part Applicability**

<b>RHS</b>
0401277850
0401287420
0401287740

**Section 3: Weight & Balance**

<u>Part Number</u>	<u>Description</u>	<u>Weight</u>	<u>Long. Arm</u>	<u>Lat. Arm</u>
AAL-255-020-002	RHS S-76 Exhaust Prolongator, R&O, Kit	nil* <i>nil (Kg)</i>	0.000 <i>0.000 (m)</i>	0.000 <i>0.000 (m)</i>

\* Total increase in weight to aircraft

**Section 4: Maintenance/Inspection Section**

1. Refer to the current revisions of the Sikorsky S-76 Maintenance Manual for Instructions for Maintenance/Inspection with respect to the item(s) referenced within this document.

**Section 5: Repair Procedures**

1. Repairs to the item(s) referenced within this document are **not** permitted. Contact Alpine Aerotech LP for further information if repairs are required to the item(s) referenced within this document.