




ALPINE AEROTECH LTD.
www.alpineaerotech.com



1260 Industrial Road, Kelowna, B.C., Canada V1Z 1G5
Phone: (250) 769-6344 Fax: (250) 769-6303
admin@alpineaerotech.com



MAIN SHAFT ACCESS DOOR, KIT MAINTENANCE MANUAL SUPPLEMENT

MODELS: BELL 212



General Notes

1. Perform Daily Inspections every day, prior to flight operation.
2. Perform 100 hour/12 month Inspections every 100 hours or every 12 months, whichever occurs first or if damage is detected in Daily Inspection, prior to flight operation.
3. Replace damaged or worn items in accordance with the applicable Installation Instructions and Illustrated Part Breakdown.
4. Repairs are not permitted. Contact Alpine Aerotech Ltd. for further information.

Daily Inspection

1. Perform a General Inspection on all items to ensure proper operation and function.
2. Perform a General Inspection on all items to ensure proper security.
3. Perform a General Inspection on the Door Assembly to ensure the Door is closed and secured.

100 Hour/12 Month Inspection

1. Perform a Detailed Inspection on all items to ensure proper operation and function.
2. Perform a Detailed Inspection on all items to ensure proper security.
3. Perform a Detailed Inspection on all fasteners/hardware to ensure proper security/torque.
4. Perform a Detailed Inspection on all materials to ensure proper integrity.
5. Perform a Detailed Inspection on the Door Assembly to ensure the Hinge Pin is tightly contained in the Hinge Halves.