

# **TRACTION PAW, ASSY INSTRUCTIONS FOR CONTINUING AIRWORTHINESS**

## **MODELS: BELL 429**

Read all of the Instructions for Continuing Airworthiness thoroughly prior to performing any activities relating to this product

## **Table of Contents**

<u>Section</u>	<u>Description</u>	<u>Page</u>
1	Description	2
2	Maintenance Manual Supplement	3
3	Installation & Removal Instructions	8
	Applicability	8
	Installation Instructions	9
	Removal Instructions	13
4	Illustrated Parts Breakdown	17

## **Notes**

1. If changes to this document are required, Alpine Aerotech LP shall revise all pages and reissue the entire document.
2. Alpine Aerotech LP shall make any subsequent revisions of this document available free of charge upon request. Alpine Aerotech LP also recommends that the end user of this product periodically verify the revision level of this document.

## **Section 1    **Description****

The following information provides a functional description of the Traction Paw, Kit as defined in Alpine Aerotech LP authority dataset AAL-490-020-001.

- In soft terrain landing situations (i.e. tundra, snow and sand) where the skid tubes can sink into the landing area, The Traction Paw, Kit provides increase floatation and damage tolerance.
- When installed, the Traction Paw, Kit provides additional flotation to the skid gear in the center of the aircraft's C of G, therefore increasing stability and flotation.

## **Section 2 Maintenance Manual Supplement**

### **General Notes**

1. The following information defines the instructions for continuing airworthiness, repair allowances and airworthiness limitations for the item(s) referenced within this document.
2. Refer to the current revision of the BHT Maintenance Manual, BHT-429-MM, for the chapter(s) and section(s) referenced within this document.
3. Refer to the Section 3: Installation & Removal Instructions and Section 4: Illustrated Parts Breakdown for the replacement and/or installation of the item(s) referenced within this section.
4. Scheduled inspection for the item(s) referenced within this document shall be accomplished in accordance with (IAW) the Inspection Procedures specified.
5. Repair allowances for the item(s) referenced within this document shall be accomplished IAW the Repair Procedures specified.
6. Limitations for the item(s) referenced within this document are IAW the Airworthiness Limitations specified.

---

### **Airworthiness Limitations**

The Airworthiness Limitations section is approved by the Minister and specifies maintenance required by any applicable airworthiness or operating rule unless an alternative program has been approved by the Minister.

The Airworthiness Limitations section is FAA approved and specifies maintenance required under Sections 43.16 and 91.403 of the Federal Aviation Regulations unless an alternative program has been FAA approved.

### **Supplement to applicable Maintenance Manual, Chapter 4, Airworthiness Limitations Schedule**

#### **Notes**

1. Refer to the applicable Maintenance Manual, Chapter 4-1 and 4-2, for general information on airworthiness limitations and airworthiness limitation schedules.
2. Item(s) **not** listed in the Scheduled Airworthiness Limitations section within this document have an unlimited airworthiness life.

#### **Scheduled Airworthiness Limitations**

1. There are no airworthiness limitations associated with the item(s) referenced within this document.

## **Inspection Procedures**

### **Supplement to applicable Maintenance Manual, Chapter 5, Inspection and Component Overhaul Schedule**

#### **Notes**

1. Refer to the applicable Maintenance Manual, Chapters 5-1, thru 5-14, for general information on inspections, inspection definitions, inspection intervals, inspection methods and inspection schedules.
2. General Inspections, as indicated within this document, are defined as visual, non-thorough checks.
3. Detailed Inspections, as indicated within this document, are defined as visual and thorough, searching checks.
4. Perform Daily Inspections every day, prior to flight operation. If damage is detected, perform the 400 Hour/12 Month Inspections.
5. Perform 400 Hour/12 Month Inspections every 400 hours or every 12 months, whichever occurs first, prior to flight operation. If damage is detected, refer to the Repair Procedures section within this document.

#### **Scheduled Inspections**

Revision: A  
Date: 2021-02-19

Doc. No.: AAL-490-025-701

Page 5 of 21

1. Daily Inspections

Data Reference: Section 3: Installation and Removal Instructions  
Section 4: Illustrated Parts Breakdown

- i. Perform a General Inspection on all items in the Traction Paw, Kit for general condition.
- ii. Perform a General Inspection on all items in the Traction Paw, Kit for proper security.

2. 400 Hour/12 Month Inspections

Data Reference: Section 3: Installation and Removal Instructions  
Section 4: Illustrated Parts Breakdown

- i. Perform a Detailed Inspection on all items, materials and finishes in the Traction Paw, Kit for evidence of corrosion, cracks and damage.
- ii. Perform a Detailed Inspection on all items in the Traction Paw, Kit for evidence of excessive wear.
- iii. Perform a Detailed Inspection on all items, materials and finishes in the Traction Paw, Kit for proper integrity and condition.
- iv. Perform a Detailed Inspection on all hardware and fasteners in the Traction Paw, Kit for proper security and torque.

**Repair Procedures**

1. Repairs to the item(s) referenced within this document are **not** permitted. Contact Alpine Aerotech LP for further information if repairs are required to the item(s) referenced within this document.

### **Section 3    Installation & Removal Instructions**

### **Applicability**

The Traction Paw, Kit (AAL-490-020-001) is applicable to all serial numbers, equipped with standard (low) landing gear only.

### **Weight & Balance**


<u>Part Number</u>	<u>Description</u>	<u>Weight</u>	<u>Long. Arm</u>	<u>Lat. Arm</u>
AAL-490-020-001	Traction Paw, Kit	27.07*	213.30	.000
		12.27 (Kg)	5.41 (m)	.00 (m)

\* Total increase in weight to aircraft.

### **General Notes**

1. All Installation Instructions shall be accomplished in accordance with (IAW) standard aircraft practices. Refer to the current revision of the FAA Advisory Circular AC 43.13-1 and AC 43.13-2 for details on standard aircraft practices.
2. Torque fasteners IAW the tension type torque limits indicated in the current revision of the FAA Advisory Circular AC 43.13-1, Table 7-1 unless otherwise specified.
3. All Dimensions are in imperial measures (inches/pounds).
4. Refer to Section 2: Maintenance Manual Supplement for instructions on maintenance for the item(s) referenced within this section.
5. Refer to Section 4: Illustrated Parts Breakdown for the part numbers of the item(s) referenced within this section.

### **Installation Notes**


 Typical item number for all like items in this view unless otherwise specified.

### **Installation Instructions - Common**

**NOTE:** LHS installation shown, RHS opposite.




1. Install the supplied hardware on the Traction Paw, Detail (Item 1) as shown. Reference Figure 1.



**Figure 1**  
Typical Hardware  
Installation

**Installation Instructions – Climbing Iron Nylatron Installed**

1. Raise the aircraft so the Traction Paw, Detail (Item 1) can be slide under the skid tube.  
Reference Figure 2.



ISOMETRIC VIEW  
LHS INSTALLATION  
SHOWN

**Figure 2**  
RHS Shown  
LHS Opposite

**Installation Instructions - Climbing Iron Nylatron Installed** (cont.)


2. Once the Traction Paw, Detail (Item 1) is under the skid tube in its approximate location, place the Cap, Detail (Item 7) & Strap, Assy's (Items 8, 9) on their corresponding bolts. Reference Figure 2.

**NOTE:** Ensure the Cap, Detail (Item 7) & Strap, Assy (Item 8) is oriented over top of the Hi-Lok Collars common to the cross tube fitting.

3. Install the supplied Washer (Item 6) and Nut (Item 4) on each bolt. Reference Figures 2 & 3.

**NOTE:** Ensure the radius edge on the Washer (Item 6) is oriented down and towards the skid tube. Reference Figure 3.

**NOTE:** A “thin-wall” socket may be required to adequately engage the Nut (Item 4).



**Figure 3**


**CAUTION:** Do **NOT** apply full torque to the fasteners at this stage while the aircraft is raised off the ground. Only apply minimal torque to snug-up the Traction Paw, Detail (Item 1).

**Installation Instructions - Climbing Iron Nylatron Installed** (cont.)

4. Lower the aircraft onto the Traction Paw, Details (Item 1) and torque the fasteners equally to 40 in/lbs. Reference Figure 3.  
  
**CAUTION:** Before applying torque, ensure the Cap, Detail (Item 7) is oriented over top of the Hi-Lok Collars common to the cross tube fitting. Reference Step 2.
5. Installation complete.
6. Perform a General Inspection of all items to ensure proper installation.
7. Update the aircraft logbook for the installation of the Traction Paw, Kit.

**Installation Instructions – Climbing Iron Nylatron Installed (Not Installed)**

1. Raise the aircraft so the Traction Paw, Detail (Item 1) can be slide under the skid tube.  
Reference Figure 4.



**Figure 4**

**Installation Instructions – Climbing Iron Nylatron Installed (Not Installed) (Cont.)**


8. Once the Traction Paw, Detail (Item 1) is under the skid tube in its approximate location, place the Cap, Details (Items 7 & 11) & Strap, Assy's (Items 8, 10) on their corresponding bolts. Reference Figure 3.

**NOTE:** Ensure the Cap, Detail (Item 7) & Strap, Assy (Items 8) is oriented over top of the Hi-Lok Collars common to the cross tube fitting.

9. Install the supplied Washer (Item 6) and Nut (Item 4) on each bolt. Reference Figures 2 & 3.

**NOTE:** Ensure the radius edge on the Washer (Item 6) is oriented down and towards the skid tube. Reference Figure 3.

**NOTE:** A “thin-wall” socket may be required to adequately engage the Nut (Item 4).



**Figure 3**

**CAUTION:** Do **NOT** apply full torque to the fasteners at this stage while the aircraft is raised off the ground. Only apply minimal torque to snug-up the Traction Paw, Detail (Item 1).

**Installation Instructions – Climbing Iron Nylatron Installed (Not Installed) (Cont.)**

10. Lower the aircraft onto the Traction Paw, Details (Item 1) and torque the fasteners equally to 40 in/lbs. Reference Figure 3.

**CAUTION:** Before applying torque, ensure the Cap, Detail (Item 7) is oriented over top of the Hi-Lok Collars common to the cross tube fitting. Reference Step 2.

11. Installation complete.
12. Perform a General Inspection of all items to ensure proper installation.
13. Update the aircraft logbook for the installation of the Traction Paw, Kit.

### **Removal Instructions**


1. As there are no special considerations or additional steps to remove the Traction Paw, Kit for either inspections, or mission configuration, the removal of the Traction Paw, Kit can be considered the opposite of installation.
2. Perform a General Inspection of all items to ensure proper removal.
3. Update the aircraft logbook for the removal of the Traction Paw, Kit.

**Section 4 Illustrated Parts Breakdown**




**General Notes**

1. Alternate items listed where applicable.


 Typical item number for all like items in this view unless otherwise specified.

**Illustrated Parts Breakdown** (cont.)




Traction Paw, Kit  
Shown  
(LHS only)

**Illustrated Parts Breakdown** (cont.)



Traction Paw, Kit  
Nylatron Installed  
Shown  
(RHS only)



Traction Paw, Kit  
Nylatron **NOT** Installed  
Shown  
(RHS only)

## Illustrated Parts Breakdown (cont.)

ITEM	QTY	NUMBER	DESCRIPTION	MATERIAL	REF	STOCK SIZE	SPEC	FINISH	MANUFACTURER	NCAGEC
-	-	AAL-490-020-001	TRACTION PAW, ASSY							
1	2	AAL-490-022-001	TRACTION PAW, DETAIL	NA	NA	NA	NA	NA	ALPINE AEROTECH LP	L0171
2	20	AAL-290-042-006	TAB, DETAIL	NA	NA	NA	NA	NA	ALPINE AEROTECH LTD.	L0171
3	20	MS15795-812	WASHER, FLAT	SEE SPEC	SEE SPEC	NASM15795	SEE SPEC	SEE SPEC	SOURCE AS REQUIRED	NA
4	40	Ø.3125-18, STYLE NE	NUT, HEX, SELF LOCKING	ASME B18.16.6 GRADE N2	SEE SPEC	ASME B18.16.6	ZINC PLATED	SEE SPEC	SOURCE AS REQUIRED	NA
5	20	Ø.3125-18 x 2.250 x 2.250	BOLT, ROUND HEAD, SQUARE NECK	ASTMA307 GRADE A	SEE SPEC	ASME B18.5	ZINC PLATED	SEE SPEC	SOURCE AS REQUIRED	NA
6	20	NAS1401-5C3	WASHER, RADIUS	SEE SPEC	SEE SPEC	NAS1401	SEE SPEC	SEE SPEC	SOURCE AS REQUIRED	NA
7	2	AAL-490-032-003	CAP, DETAIL	NA	NA	NA	NA	NA	ALPINE AEROTECH LP	L0171
8	2	AAL-490-011-004	STRAP, ASSY	NA	NA	NA	NA	NA	ALPINE AEROTECH LTD.	L0171
9	8	AAL-490-021-001	STRAP, ASSY	NA	NA	NA	NA	NA	ALPINE AEROTECH LP	L0171
10	8	AAL-490-021-002	STRAP, ASSY	NA	NA	NA	NA	NA	ALPINE AEROTECH LP	L0171
11	8	AAL-490-022-006	CAP, DETAIL	NA	NA	NA	NA	NA	ALPINE AEROTECH LP	L0171