




ALPINE AEROTECH LTD.



SHOULDER HARNESS KIT INSTALLATION INSTRUCTIONS

MODELS: BELL 205 & 210*



Read all of the instructions thoroughly prior to the installation of this product.

* IAW FAA STC SR01188NY for US registered Bell Helicopter 210 rotorcraft only.



ALPINE AEROTECH LTD.

INSPECTION

Refer to the current revision of the Shoulder Harness, Kit Maintenance Manual Supplement (191M-2000-016-MMS) for instructions on continuing airworthiness for the item(s) referenced within this document.

WEIGHT & BALANCE

| <u>Part Number</u> | <u>Description</u> | <u>Weight</u> (Lbs.) | <u>Long. Arm</u> (Inches) | <u>Lat. Arm</u> (Inches) |
|--------------------|-----------------------|-------------------------|------------------------------|-----------------------------|
| AAL-370-711-002 | Complete Kit | 33.76* | 115.90 | 0.00 |
| AAL-370-711-003 | Front 9 Kit | 25.81* | 108.74 | 0.00 |
| AAL-370-711-013 | 2 Person LHS Seat Kit | 3.97* | 139.16 | 15.72 (LBL) |
| AAL-370-711-014 | 2 Person RHS Seat Kit | 3.97* | 139.16 | 15.72 (RBL) |
| AAL-370-711-015 | 5 Person Seat Kit | 16.60* | 127.56 | 0.00 |
| AAL-370-711-016 | 4 Person Seat Kit | 9.21* | 74.80 | 0.00 |

* Weight excludes new lap belts

INSTALLATION NOTES

- 1) All instructions, where applicable, are to be completed using standard aircraft sheet metal and maintenance practices.
- 2) All hardware must be torqued to standard specs.
- 3) Reference numbers in installation correspond to dash numbers on Parts List.

 Install Button Plug (Item 154) with Loctite 401 Prism Adhesive.


INSTALLATION, SECTION A

2 PERSON OUTBOARD FACING SEATS

- 1) Unbutton the top half of the soundproofing blankets on the vertical side walls of the pylon.
- 2) Remove the necessary bolts retaining the upper, side pylon inspection panels and install the bracket assemblies, -033 LHS FWD/-034 RHS FWD and -037 LHS AFT/-038 RHS AFT, and hardware as shown. Reference Figure 1.



ALPINE AEROTECH LTD.




LHS SHOWN, RHS OPPOSITE
FIGURE 1


- 3) Cut 3/4" dia. holes in the soundproofing blankets, 4 places per side, and sew the edges as required. Cut the holes in the same locations as the mounting holes for the inertia reels and belt guide assemblies as shown. Reference Figure 1.
- 4) Reinstall the soundproofing blankets.
- 5) Install the inertia reels, -131, belt guide assemblies, -044, and hardware as shown. Install the hardware with Loctite 243 threadlocker as required. Reference Figure 2&3.
- 6) Place the webbing from the inertia reels through the belt guide assemblies, -044, as shown and install the hardware. Apply Anti-Tamper/Witness Paint to the hardware and guide frame as shown. Reference Figure 4.




ALPINE AEROTECH LTD.



TYP REEL INSTALLATION
FIGURE 2



TYP GUIDE INSTALLATION
FIGURE 3




TYP GUIDE ASSEMBLY
FIGURE 4



ALPINE AEROTECH LTD.


- 7) Remove the existing lap belts and install the new lap belt buckle halves, -129, connector halves, -128, and shoulder harness straps as shown. Reference Figure 5&6.



LHS SHOWN, RHS OPPOSITE
FIGURE 5




ALPINE AEROTECH LTD.



TYP BELT INSTALLATION
FIGURE 6

- 8) Install the cotter pins, -130, into the hook ends, 4 places per side, of the lap belts. Reference Figure 7.



TYP COTTER PIN INSTALLATION
FIGURE 7

INSTALLATION, SECTION B

5 PERSON FWD FACING SEATS

- 1) Remove the soundproofing blanket on the vertical FWD wall of the pylon.
- 2) Remove the two (2) rivets at the intersections of WL 63.93, LBL 6.76 and WL 63.93, RBL 6.76 on the FWD wall of the pylon as shown. Reference Figure 8.

NOTE: Be careful not to damage any hardware or hydraulic lines on the backside of the wall when removing the rivets.



ALPINE AEROTECH LTD.





FIGURE 8

- 3) Place the doublers, -112, on the backside of the wall and transfer the rivet hole locations into each doubler as shown. Open up the holes in the wall and doublers to .203" dia. (13/64). Reference Figure 8&9.

NOTE: Access for this operation can be easily obtained through the lower, side pylon inspection panels. Reference Figure 5.



ALPINE AEROTECH LTD.



LHS SHOWN, RHS OPPOSITE
FIGURE 9




ALPINE AEROTECH LTD.

- 4) Install the bracket assemblies, -039 LHS/-040 RHS, and spot the rivet hole locations from the wall into the brackets as shown. Remove the brackets and drill the holes through, .203" dia. (13/64). Drill the holes 90 degrees to the face of the brackets. This operation should be performed on a drill press. Reference Figure 8,9,10.

NOTE: The rubber padding surrounding the hi-loks on the fwd pylon wall may require trimming to install the bracket assemblies.

- 5) Apply anticorrosion primer to the insides of the previously drilled holes in the bracket assemblies, -039/-040, doublers, -112, and FWD wall of the pylon.



TYP BOLT INSTALLATION
FIGURE 10

- 6) Reinstall the bracket assemblies and hardware as shown. Install -141 with Loctite 243 threadlocker as required. Reference Figure 8,9,10.
- 7) Cut 3/4" dia. holes in the soundproofing blankets, 4 places per side, and sew the edges as required. Cut the holes in the same locations as the mounting holes for the inertia reels and belt guide assemblies as shown. Reference Figure 8.
- 8) Reinstall the soundproofing blankets.
- 9) Install the inertia reels, -131, belt guide assemblies, -044, and hardware as shown. Install the hardware with Loctite 243 threadlocker as required. Reference Figure 2&3.
- 10) Place the webbing from the inertia reels through the belt guides assemblies, -044, as shown and install the hardware. Apply Anti-Tamper/Witness Paint to the hardware and guide frame as shown. Reference Figure 4.
- 11) Remove the necessary hardware from the stanchion posts and install the stanchion post collar assemblies, -041, hardware, and inertia reels, -131 as shown. Install -140 with Loctite 243 threadlocker as required. Reference Figure 11&12.



ALPINE AEROTECH LTD.




FIGURE 11




FIGURE 12

LHS SHOWN, RHS OPPOSITE

- 12) Remove the existing lap belts and Install the new lap belt buckle halves, -129, connector halves, -128, and shoulder harness straps as shown. Reference Figure 6&13.



ALPINE AEROTECH LTD.




FIGURE 13

- 13) Install the cotter pins, -130, into the hook ends, 10 places, of the lap belts. Reference Figure 7.




ALPINE AEROTECH LTD.

INSTALLATION, SECTION C

4 PERSON AFT FACING SEATS

- 1) Remove the hardware from the lap belt I-bolts and install the reel brackets, -119 OUTBD/-120 INBD, hardware, and inertia reels, -132, as shown. Reference Figure 14.






TYP REEL INSTALLATION
FIGURE 14

- 2) Remove the headrests and necessary hardware from the seat and install the support tube connectors, -117, support tube saddles, -118, tube assemblies, -042, and hardware as shown. Reinstall the headrests. Reference Figure 15 and isometric drawing on cover page.



ALPINE AEROTECH LTD.



UP

OUTBD

VIEW LKG FWD LHS

LHS SHOWN, RHS OPPOSITE

FIGURE 15



ALPINE AEROTECH LTD.

- 3) Remove the existing lap belts and install the new lap belt buckle halves, -157, connector halves, -156, and shoulder harness straps as shown. Reference Figure 6&16.





FIGURE 16

- 4) Install the cotter pins, -130, into the hook ends, 8 places, of the lap belts. Reference Figure 7.